

Skeem	Varjatud montaažiks sobivad segistid
	<p>Otsemontaaž seinale RS 062, NO 062, TD 062, TD F 062, CL 062, CR 064</p> <p>R-boxi kasutamine RB 070.50 RS 066, NO 066, CR 066, TD 066, TD F 066, CL 066</p>
	<p>Otsemontaaž seinale RS 061, NO 061, TD 061, TD F 061, CL 061</p> <p>R-boxi kasutamine RB 070.50 RS 065, NO 065, CR 065, TD 065, TD F 065, CL 065</p>
	<p>Otsemontaaž seinale CR 063</p>
	<p>R-boxi kasutamine Multi RB 071.50 CR 067.00</p>

SEGISTITE VEEVOOLUDE TÄHISTUSED RAVAK									
Veekulu on ära toodud l/min, surve korral 0,3 MPa									
RAVAK kood	Kraanikauss	Valamu	Bidee	Vann	Üladušš	Käsiduši otsak	OUT 1	OUT 2	OUT 3
PU 014.00	12								
PU 015.00	12								
PU 022.00/150				19		11			
PU 033.00/150						22			
TE 022.00/150				17		18			
TE 023.00/150				21		22			
TE 032.00/150						23			
TE 033.00/150						24			
TE 072.00/150						23			
TE 082.00/150				21		26			
TE 091.00/150					19	12			
TE 092.00/150				17	12	10			
TE 093.00/150					14	11			
TD F 011.00	5								
TD F 012.00	5								
TD F 013.00	5								
TD F 014.00	5								
TD F 015.00	5								
TD F 055.00			15						
TD F 022.00/150				19		21			
TD F 032.00/150						21			
TD F 061.00							22	21	
TD F 062.00							26		
TD F 065.00							21	21	
TD F 066.00							22		
TD 011.00	5								
TD 012.00	5								
TD 013.00	5								
TD 014.00	5								
TD 015.00	5								
TD 022.00/150				19		21			
TD 032.00/150						21			
TD 033.00/150						24			
TD 055.00			15						
TD 061.00							22	21	
TD 062.00							26		
TD 065.00							21	21	
TD 066.00							22		
TD 091.00/150					14	11			
CR 011.00	8								
CR 012.00	8								
CR 015.00	8								
CR 016.00		15							
CR 019.00	8								
CR 022.00/150				16		17			
CR 025.00				16		11			
CR 032.00/150						20			
CR 055.00			15						
CR 063.00							20	20	
CR 064.00							20		
CR 065.00							21	20	
CR 066.00							21		
CR 067.00							16	17	17
CR 080.00				21		14			
CR 112.00	7					6			
DS 090.00					14	10,5			

Skeem	Varjatud montaažiks sobivad segistid
	<p>Otsemontaaž seinale RS 062, NO 062, TD 062, TD F 062, CL 062, CR 064</p> <p>R-boxi kasutamine RB 070.50 RS 066, NO 066, CR 066, TD 066, TD F 066, CL 066</p>
	<p>Otsemontaaž seinale RS 061, NO 061, TD 061, TD F 061, CL 061</p> <p>R-boxi kasutamine RB 070.50 RS 065, NO 065, CR 065, TD 065, TD F 065, CL 065</p>
	<p>Otsemontaaž seinale CR 063</p>
	<p>R-boxi kasutamine Multi RB 071.50 CR 067.00</p>

SEGISTITE VEEVOOLUDE TÄHISTUSED RAVAK										
Veekulu on ära toodud l/min, surve korral 0,3 MPa										
RAVAK kood	Kraanikauss	Valamu	Bidee	Vann	Üladušš	Käsi duši otsak	OUT 1	OUT 2	OUT 3	
CL 011.00	11									
CL 012.00	11									
CL 016.00		8								
CL 022.00/150				15		11				
CL 032.00/150						17				
CL 055.00			10							
CL 061.00							22	23		
CL 062.00							24			
CL 065.00							20	20		
CL 066.00							20			
NO 011.00	17									
NO 012.00	16									
NO 022.00/150				20		22				
NO 032.00/150						24				
NO 055.00			16							
NO 061.00							24	25		
NO 062.00							26			
NO 065.00							22	22		
NO 066.00							23			
RS 011.00	17									
RS 012.00	17									
RS 022.00/150				21		22				
RS 025.00				19		12				
RS 032.00/150						22				
RS 051.00/150	19					21				
RS 055.00	17									
RS 061.00							24	24		
RS 062.00							26			
RS 065.00							21	21		
RS 066.00							22			
SN 011.00	16									
SN 012.00	16									
SN 015.00	16									
SN 016.00	16									
SN 022.00/100				15		17				
SN 022.00/150				17		17				
SN 032.00/100						20				
SN 032.00/150						22				
SN 041.00/100	18									
SN 041.00/150	18									
WF 025.00				25		11				
KM 016.00		14								
KM 017.00		7								
FM 016.00		18								
FM 080.00				19		13				
FM 081.00				20		14				
BM 011.00	11					6				
BM 040.00						11				